



ALPHA DATA

Common Host Utilities Release: 1.9.0

**Document Revision: 1.1
16th May 2015**

© 2015 Copyright Alpha Data Parallel Systems Ltd.

All rights reserved.

This publication is protected by Copyright Law, with all rights reserved. No part of this publication may be reproduced, in any shape or form, without prior written consent from Alpha Data Parallel Systems Ltd.

Head Office

Address: 4 West Silvermills Lane,
Edinburgh, EH3 5BD, UK
Telephone: +44 131 558 2600
Fax: +44 131 558 2700
email: sales@alpha-data.com
website: <http://www.alpha-data.com>

US Office

3507 Ringsby Court Suite 105,
Denver, CO 80216
(303) 954 8768
(866) 820 9956 toll free
sales@alpha-data.com
<http://www.alpha-data.com>

All trademarks are the property of their respective owners.

Table Of Contents

1	Introduction	1
1.1	Directory structure	1
2	Building the Common Host Utilities	3
2.1	Building with Visual Studio 2012	3
2.2	Building with Visual Studio 2013	3
2.3	Building in Linux	3
2.3.1	Building SYSMON in Linux	4
3	Common Host Utilities	5
3.1	AVR2UTIL utility	5
3.2	BITSTRIP utility	7
3.3	DMADUMP utility	7
3.4	DUMP utility	10
3.5	FLASH utility	13
3.5.1	Region to address range mapping	16
3.6	INFO utility	17
3.7	IPROG utility	19
3.8	LOADER utility	21
3.9	MONITOR utility	22
3.10	SYSMON utility	22
3.10.1	SYSMON device information tab	24
3.10.2	SYSMON sensor information tab	24
3.10.3	SYSMON sensor readout tab	24
3.10.4	SYSMON device status tab	25
3.10.5	SYSMON clock generator tab	26
3.10.6	SYSMON sensor data logging	27
3.11	VPD utility	29
Appendix A	AVR2UTIL clock generator indices	33
A.1	ADM-XRC-KU1	33
A.2	ADM-PCIE-8V3	33
A.3	ADM-PCIE-8K5	34

List of Tables

Table 1	Utilities for Windows and Linux	1
Table 2	AVR2UTIL clock generator indices (ADM-XRC-KU1)	33
Table 3	AVR2UTIL clock generator indices (ADM-PCIE-8V3)	33
Table 4	AVR2UTIL clock generator indices (ADM-PCIE-8K5)	34

List of Figures

Figure 1	Directory structure	2
Figure 2	SYSMON user interface	23
Figure 3	SYSMON notification area icon	24
Figure 4	SYSMON sensor information tab	24
Figure 5	SYSMON sensor readout tab	25
Figure 6	SYSMON device status tab	26
Figure 7	SYSMON clock generator tab	27

Figure 8	SYSMON Action menu in Linux	28
Figure 9	SYSMON Action menu in Windows	28

1 Introduction

This document describes the Common Host Utilities, for Alpha Data Gen 3 Reconfigurable Computing Hardware. In this context, "common" refers to the fact that these utilities, with some exceptions, can be used with all models in Alpha Data's range of Gen 3 Reconfigurable Computing Hardware:

- Embedded system products:
 - ADM-XRC-6TL
 - ADM-XRC-6T1
 - ADM-XRC-6T-DA1
 - ADM-XRC-6TGE and ADM-XRC-6TGEL
 - ADM-XRC-6T-ADV8
 - ADPE-XRC-6T and ADPE-XRC-6T-L
 - ADM-XRC-7K1
 - ADM-XRC-7V1
 - ADM-VPX3-7V2
 - ADM-XRC-KU1
- Datacenter products:
 - ADM-PCIE-7V3
 - ADM-PCIE-KU3
 - ADM-PCIE-8V3
 - ADM-PCIE-8K5

Table 1 lists the available utilities for Windows and Linux.

AVR2UTIL	Utility for manipulating microcontroller firmware and related data (for certain models only).
BITSTRIP	Utility for removing the header from a .bit file, leaving only the SelectMap data
DMADUMP	Utility for reading and writing using DMA engines
DUMP	Utility for reading and writing memory windows
FLASH	Utility for programming FPGA bitstream (.BIT) files in user-programmable Flash memory
INFO	Utility for displaying information about a reconfigurable computing device
IPROG	Utility for software-initiated reconfiguration of a target FPGA from Flash memory
LOADER	Utility for configuring a target FPGA with a bitstream file
MONITOR	Utility that displays sensor readings
SYSMON	Utility that combines the functionality of the INFO and MONITOR utilities in a graphical user interface
VPD	Utility that allows the Vital Product Data of a reconfigurable computing device to be read or written

Table 1 : Utilities for Windows and Linux

1.1 Directory structure

The files and folders making up the Common Host Utilities are organized as in Figure 1 below:




Figure 1 : Directory structure

The root of this package, i.e. the directory which forms the root of tree of directories and files making up this package, is referred to in the remainder of this document as **(root)**.

The base directory of the Common Host Utilities, i.e. **(root)/host/util-v1_9_0/** is referred to in the remainder of this document as **(util)**, or as **\$(util)** in example shell commands.

2 Building the Common Host Utilities

2.1 Building with Visual Studio 2012

A Microsoft Visual Studio 2012 solution (`util\proj\win32vs2012\util.sln`) is provided, containing projects for all of the utilities. To build all of the utilities, use the "Batch Build" command in the Microsoft Visual Studio 2012 IDE.

Note

Building the utilities does not update the `(util)\bin\x86\` or `(util)\bin\x64\` folders.

2.2 Building with Visual Studio 2013

A Microsoft Visual Studio 2013 solution (`util\proj\win32vs2013\util.sln`) is provided, containing projects for all of the utilities. To build all of the utilities, use the "Batch Build" command in the Microsoft Visual Studio 2013 IDE.

Note

Building the utilities does not update the `(util)\bin\x86\` or `(util)\bin\x64\` folders.

2.3 Building in Linux

To build all of the host utilities at once, excluding the `SYSMON` utility, enter the following shell commands in a BASH shell:

```
$ cd $(util)/proj/linux
$ make clean all
```

Note

The `SYSMON` utility must be built separately, because it depends upon certain packages being installed in the system. For further details, refer to [Section 2.3.1](#).

A number of variables, passed on the `make` command line, and certain environmental variables can modify the way the utilities are built:

- **BIARCH**

For most `x86_64` Linux distributions, it is possible to build both a native (64-bit) executable and a 32-bit executable. To do this, set `BIARCH` variable to `yes` on the `make` command-line. For example:

```
make BIARCH=yes clean all
```

Assuming that building is successful, the 32-bit executable has the suffix "32" whereas the native executable has no suffix. For example, in the case of the `INFO`, the executables are named `info` (native 64-bit) and `info32` (32-bit).

- **CROSS_COMPILE**

To build using a cross-compiler, set the `CROSS_COMPILE` environment variable to the prefix of the toolchain binaries, ensuring that the toolchain is in the `PATH`. For example

```
export PATH=/path/to/toolchain:$PATH
export CROSS_COMPILE=arm-none-linux-gnueabi-
make clean all
```

- **SYSROOT**

Generally used only when cross-compiling, the value of `SYSROOT` points to the target system's root filesystem. This may be required if the toolchain used for cross-compiling does not have the required defaults for paths to system header files and libraries directories. For example:

```
export PATH=/path/to/toolchain:$PATH
export CROSS_COMPILE=arm-none-linux-gnueabi-
make SYSROOT=/path/to/arm-rootfs clean all
```

2.3.1 Building SYSMON in Linux

The Linux version of the **SYSMON** utility uses **GTKMM-2.4** or **GTKMM-3.0** for building its graphical user interface. This package is present in recent Linux distributions, but may not be present in older Linux distributions. For this reason, **SYSMON** is built separately from the other example applications. A non-exhaustive list of the packages that are required to build **SYSMON** is as follows:

gtkmm24-devel or gtkmm30-devel	cairomm-devel
libsigc++20-devel	glibmm24-devel
pangomm-devel	pkgconfig

To run **SYSMON**, the corresponding runtime packages are required:

gtkmm24 or gtkmm30	cairomm
libsigc++20	glibmm24
pangomm	

To build the "Release" configuration of **SYSMON**, enter the following commands in a BASH shell:

```
$ cd $(util)/proj/linux/sysmon
$ make CONFIG=Release clean all
```

The executable's path is then **(util)/proj/linux/sysmon/bin/Release/sysmon**.

3 Common Host Utilities

3.1 AVR2UTIL utility

Command line

```
avr2util [option ...] getclkv      clockgen-index  
avr2util [option ...] setclkv      clockgen-index frequency  
avr2util [option ...] update-brdcfg config-filename  
avr2util [option ...] update-firmware firmware-filename  
avr2util [option ...] update-vpd   vpd-filename  
avr2util [option ...] version
```

The following options are accepted:

-index <index>	Specifies the index of the card to open (default 0).
-sn <#>	Specifies the serial number of the card to open.
+verbose	Dumps commands sent to the microcontroller and its responses, for debug purposes.

Summary

This utility performs maintenance functions on the firmware of the microcontroller and associated data.

As of writing, **AVR2UTIL** supports the following models:

- ADM-XRC-KU1
- ADM-PCIE-8V3
- ADM-PCIE-8K5

Description

The **AVR2UTIL** utility currently has six commands:

- **getclkv** <clockgen-index>
Gets the nonvolatile override frequency for the particular clock generator selected by <clockgen-index>.
- **setclkv** <clockgen-index> <frequency>
Sets the nonvolatile override frequency for the particular clock generator selected by <clockgen-index> to <frequency> Hz.
- **update-brdcfg** <brdcfg-filename>
Writes the board-specific configuration area used by the microcontroller firmware with the contents of the file <brdcfg-filename>.
NOTE: This command should be used only under guidance from Alpha Data, because incorrect usage can corrupt data required by the microcontroller's firmware.
- **update-firmware** <firmware-filename>
Writes the firmware of the microcontroller with the contents of the file <firmware-filename>.
NOTE: This command should be used only under guidance from Alpha Data, because incorrect usage can corrupt the microcontroller's firmware.
- **update-vpd** <vpd-filename>
Writes the Vital Product Data (VPD) for the board with contents of the file <vpd-filename>.

NOTE: This command should be used only under guidance from Alpha Data, because incorrect usage can corrupt the board's VPD.

- **version**

Displays the version of the microcontroller firmware.

getclknv command

The **getclknv** command returns the current nonvolatile override frequency, in Hz, for a particular clock generator.

At power-on, the microcontroller inspects each clock generator's nonvolatile override frequency in turn. If set to a value other than 0 or 4294967295, it programs the clock generator to output a clock of that frequency. Otherwise, the clock generator remains at its factory default frequency.

The general form of this command is:

```
avr2util [option ...] getclknv <clockgen-index>
```

For the correspondence of <clockgen-index> to physical clock nets, refer to [Appendix A](#).

setclknv command

The **setclknv** command sets the nonvolatile override frequency, in Hz, for a particular clock generator. This command does **not** cause the specified clock generator's actual output frequency to change immediately.

At power-on, the microcontroller inspects each clock generator's nonvolatile override frequency in turn. If set to a value other than 0 or 4294967295, it programs the clock generator to output a clock of that frequency. Otherwise, the clock generator remains at its factory default frequency.

To unset the nonvolatile override frequency for a particular clock generator, set it to 0.

The general form of this command is:

```
avr2util [option ...] setclknv <clockgen-index> <frequency>
```

For the correspondence of <clockgen-index> to physical clock nets, refer to [Appendix A](#).

update-brdcfg command

The **update-brdcfg** command writes a block of data required by the microcontroller firmware with the contents of the specified file (usually with a **.bin** extension).

NOTE: This command should be used only under guidance from Alpha Data, because incorrect usage can corrupt data required by the microcontroller's firmware.

The general form of this command is:

```
avr2util [option ...] update-brdcfg <brdcfg-filename>
```

update-firmware command

The **update-brdcfg** command writes the firmware of the microcontroller firmware with the contents of the specified file (usually with a **.bin** extension).

NOTE: This command should be used only under guidance from Alpha Data, because incorrect usage can corrupt the microcontroller's firmware.

The general form of this command is:

```
avr2util [option ...] update-firmware <firmware-filename>
```

update-vpd command

Writes the Vital Product Data (VPD) with the contents of the specified file (usually with a **.bin** extension).

NOTE: This command should be used only under guidance from Alpha Data, because incorrect usage can corrupt the board's VPD.

The general form of this command is:

```
avr2util [option ...] update-vpd <vpd-filename>
```

version command

The **version** command displays the version of the microcontroller firmware in the form *a.b.c.d* where *a*, *b*, *c* and *d* are 16-bit numbers. This command can be used as a further check in order to verify that a previous **update-firmware** command was successful (assuming that the new firmware version differs from the old firmware version).

The general form of this command is:

```
avr2util [option ...] version
```

3.2 BITSTRIP utility

Command line

```
bitstrip [option ...] <input .bit filename>
```

where the following options are accepted:

-o <output filename> Specifies the name of the file into which the SelectMap data is written.

Summary

Reads an FPGA bitstream (.bit) file, displays certain information from the header, and optionally writes the SelectMap data to another file.


Description

To simply display information from a .bit file's header, use

```
bitstrip <input .bit filename>
```

To display information from a .bit file's header and write the SelectMap data to another file, use

```
bitstrip -o <output filename> <input .bit filename>
```

The data written to <output filename> is suitable for sending to a target FPGA using [ADMXRC3_ConfigureFromBuffer](#) .

3.3 DMADUMP utility

Command line

```
dmadump [option ...] fb channel address [n] [fill value]
dmadump [option ...] fw channel address [n] [fill value]
dmadump [option ...] fd channel address [n] [fill value]
dmadump [option ...] fq channel address [n] [fill value]
dmadump [option ...] rb channel address [n]
dmadump [option ...] rw channel address [n]
```

```
dmadump [option ...] rd channel address [n]
dmadump [option ...] rq channel address [n]
dmadump [option ...] wb channel address [n] [data ...]
dmadump [option ...] ww channel address [n] [data ...]
dmadump [option ...] wd channel address [n] [data ...]
dmadump [option ...] wq channel address [n] [data ...]
```

where

<i>channel</i>	is the index of the DMA engine / DMA channel to use.
<i>address</i>	is the local address (generally an OCP address) at which to begin reading or writing.
<i>n</i>	is the number of bytes to read or write (optional).
<i>fill value</i>	is an optional fill value, valid for fill commands.
<i>data</i>	is an optional data item, valid for write commands.

and the following options are accepted:

-index <index>	Specifies the index of the card to open (default 0).
-sn <#>	Specifies the serial number of the card to open.
-be	Causes the data to be read or written to be treated as little-endian (default).
+be	Causes the data to be read or written to be treated as big-endian.
-hex	Causes write values to be interpreted as decimal unless prefixed by '0x' (default).
+hex	Causes write values to be interpreted as hexadecimal always.

Summary

Displays data read from a target FPGA using a DMA engine, or writes data to a target FPGA using a DMA engine.

Description

The **DMADUMP** utility operates in of three modes:

- Reading data from a target FPGA using a DMA engine and displaying it; for this mode, use the **rb**, **rw**, **rd** or **rq** commands.
- Writing data to a target FPGA using a DMA engine; for this mode, use the **wb**, **ww**, **wd** or **wq** commands.
- Filling an address region in a target FPGA using a DMA engine with a particular value; for this mode, use the **fb**, **fw**, **fd** or **fq** commands.

The option **+be** may be specified, before the command. This causes the **DMADUMP** utility to use big-endian byte ordering convention as opposed to little-endian (the default).

Read commands

The read command implies the word width for displaying data:

- **rb**
Byte (8-bit) reads; data is displayed as bytes.
- **rw**

Word (16-bit) reads; data is displayed as words.

- **rd**
Doubleword (32-bit) reads; data is displayed as doublewords.
- **rq**
Quadword (64-bit) reads; data is displayed as quadwords.

After the read command, a DMA channel/engine index and an address must be supplied, in that order. This specifies the DMA engine to use, and where in that DMA engine's address space to begin reading data. An optional length parameter, in bytes, can also be supplied. If omitted, the length is equal to the word width implied by the read command. If present, the length parameter specifies how many bytes to read and display. The length should be an integer multiple of the width; if not, the length is rounded down.

Write commands

The write command implies the word width to be used when performing writes:

- **wb**
Data is written as bytes (8-bit).
- **ww**
Data is written as words (16-bit).
- **wd**
Data is written as doublewords (32-bit).
- **wq**
Data is written as quadwords (64-bit).

After the write command, a DMA channel/engine index and an address must be supplied, in that order. This specifies which DMA engine to use for writing the data, and where in that DMA engine's address space to begin writing the data. An optional length parameter, in bytes, can also be supplied. If omitted, the length is equal to the word width implied by the write command. If present, the length parameter specifies how many bytes to write. The length should be an integer multiple of the width; if not, the length is rounded down.

The program obtains the values to be written in two ways: from any additional parameters on the command line after the length parameter, and then from the standard input stream (stdin). This works as follows:

- 1 Any remaining command line arguments, if present after the length parameter, are interpreted as data values to be written. These values are assumed to be of the word width implied by the command, and are written using the specified DMA engine, incrementing the address with each word written. If there are enough values passed on the command line to satisfy the byte count, the program terminates.
- 2 If there are insufficient data values passed on the command line, the program waits for values to be entered on the standard input stream. Values entered this way are also assumed to be of the word width implied by the command, and are written using the specified DMA engine, incrementing the address with each word written. When the entire byte count that was specified in the length parameter has been satisfied or end-of-file is encountered, the program terminates.

Fill commands

The fill command implies the word width to be used when performing a fill:

- **fb**
The fill value is a byte value (8-bit).
- **fw**
The fill value is a word value (16-bit).
- **fd**

The fill value is a double word value (32-bit).

- **fq**

The fill value is a quadword value (64-bit).

After the fill command, a DMA channel/engine index and an address must be supplied, in that order. This specifies the DMA engine to use, and where in that DMA engine's address space to begin writing data. An optional length parameter, in bytes, can also be supplied. If omitted, the length is equal to the word width implied by the write command. If present, the length parameter specifies how many bytes to write. The length should be an integer multiple of the width; if not, the length is rounded down.

The fill value is obtained in one of two ways: from an additional parameter on the command line after the length parameter, or from the standard input stream (stdin). There must be exactly one fill value.

Example session

Assuming that the target FPGA is currently configured with an FPGA bitstream which has a RAM-like region in the OCP/AXI address space of DMA channel 0 at address 0x80000, an example session looks like this:

```
# ./dmadump fb 0 0x80000 0x20 0xee
Fill value: 0xEE
# ./dmadump rd 0 0x80000 0x40
Dump of memory at 0x00000000_00080000 + 64 (0x40) bytes:
      00      04      08      0C
0x00000000_00080000: EEEEEEEE EEEEEEEE EEEEEEEE EEEEEEEE .....
0x00000000_00080010: EEEEEEEE EEEEEEEE EEEEEEEE EEEEEEEE .....
0x00000000_00080020: 00000000 00000000 00000000 00000000 .....
0x00000000_00080030: 00000000 00000000 00000000 00000000 .....
# ./dmadump wd 0 0x80004 0x4 0xdeadbeef
0x00000000_00080004: 0xDEADBEEF
# ./dmadump rd 0 0x80000 0x40
Dump of memory at 0x00000000_00080000 + 64 (0x40) bytes:
      00      04      08      0C
0x00000000_00080000: EEEEEEEE DEADBEEF EEEEEEEE EEEEEEEE .....
0x00000000_00080010: EEEEEEEE EEEEEEEE EEEEEEEE EEEEEEEE .....
0x00000000_00080020: 00000000 00000000 00000000 00000000 .....
0x00000000_00080030: 00000000 00000000 00000000 00000000 .....
```

Remarks

When entering data for write commands, values are expressed in decimal by default. To express data as hexadecimal, prefix it with '0x' or use the **+hex** option.

Each DMA engine has its own address space. This means that in general, unless an FPGA design explicitly makes a shared resource available to multiple DMA engines, writing data using one DMA engine and then attempting to read it back using a different DMA engine will not return the data just written.

The Direct Slave address space is separate from the address space of each DMA engine. This means that in general, writing data using the **DMADUMP** utility and attempting to read it back via the **DUMP** utility will not return the same data. However, it is possible to create an FPGA design which explicitly makes a shared resource available in both the Direct Slave address space and the address space of a DMA engine. In that case, data written by one channel can be read back via another channel.

3.4 DUMP utility

Command line

```
dump [option ...] fb window offset [n] [fill value]
dump [option ...] fw window offset [n] [fill value]
dump [option ...] fd window offset [n] [fill value]
```

```
dump [option ...] fq window offset [n] [fill value]
dump [option ...] rb window offset [n]
dump [option ...] rw window offset [n]
dump [option ...] rd window offset [n]
dump [option ...] rq window offset [n]
dump [option ...] wb window offset [n] [data ...]
dump [option ...] ww window offset [n] [data ...]
dump [option ...] wd window offset [n] [data ...]
dump [option ...] wq window offset [n] [data ...]
```

where

<i>window</i>	is the memory window to read or write.
<i>offset</i>	is the offset into the window at which to begin reading or writing.
<i>n</i>	is the number of bytes to read or write (optional).
<i>fill value</i>	is an optional fill value, valid for fill commands.
<i>data</i>	is an optional data item, valid for write commands.

and the following options are accepted:

-index <index>	Specifies the index of the card to open (default 0).
-sn <#>	Specifies the serial number of the card to open.
-be	Causes the data to be read or written to be treated as little-endian (default).
+be	Causes the data to be read or written to be treated as big-endian.
-hex	Causes write values to be interpreted as decimal unless prefixed by '0x' (default).
+hex	Causes write values to be interpreted as hexadecimal always.

Summary

Displays data read from a memory access window, or writes data to a memory access window.

Description

The **DUMP** utility operates in of three modes:

- Reading data from a memory access window and displaying it; for this mode, use the **rb**, **rw**, **rd** or **rq** commands.
- Writing data to a memory access window; for this mode, use the **wb**, **ww**, **wd** or **wq** commands.
- Filling a region of a memory access window with a particular value; for this mode, use the **fb**, **fw**, **fd** or **fq** commands.

The option **+be** may be specified, before the command. This causes the **DUMP** utility to use big-endian byte ordering convention as opposed to little-endian (the default).

Read commands

The read command implies the word width for displaying data:

- **rb**
Byte (8-bit) reads; data is displayed as bytes.

- **rw**
Word (16-bit) reads; data is displayed as words.
- **rd**
Doubleword (32-bit) reads; data is displayed as doublewords.
- **rq**
Quadword (64-bit) reads; data is displayed as quadwords.

After the read command, a window index and an offset must be supplied, in that order. This specifies the memory access window to be read, and where in that window to begin reading data. An optional length parameter, in bytes, can also be supplied. If omitted, the length is equal to the word width implied by the read command. If present, the length parameter specifies how many bytes to read and display. The length should be an integer multiple of the width; if not, the length is rounded down.

Write commands

The write command implies the word width to be used when performing writes:

- **wb**
Data is written as bytes (8-bit).
- **ww**
Data is written as words (16-bit).
- **wd**
Data is written as doublewords (32-bit).
- **wq**
Data is written as quadwords (64-bit).

After the write command, a window index and an offset must be supplied, in that order. This specifies the memory access window to be written, and where in that window to begin writing data. An optional length parameter, in bytes, can also be supplied. If omitted, the length is equal to the word width implied by the write command. If present, the length parameter specifies how many bytes to write. The length should be an integer multiple of the width; if not, the length is rounded down.

The program obtains the values to be written in two ways: from any additional parameters on the command line after the length parameter, and then from the standard input stream (stdin). This works as follows:

- 1 Any remaining command line arguments, if present after the length parameter, are interpreted as data values to be written. These values are assumed to be of the word width implied by the command, and are written to the memory window, incrementing the offset with each word written. If there are enough values passed on the command line to satisfy the byte count, the program terminates.
- 2 If there are insufficient data values passed on the command line, the program waits for values to be entered on the standard input stream. Values entered this way are also assumed to be of the word width implied by the command, and are written to the memory window, incrementing the offset with each word written. When the entire byte count that was specified in the length parameter has been satisfied or end-of-file is encountered, the program terminates.

Fill commands

The fill command implies the word width to be used when performing a fill:

- **fb**
The fill value is a byte value (8-bit).
- **fw**
The fill value is a word value (16-bit).

- **fd**
The fill value is a double word value (32-bit).
- **fq**
The fill value is a quadword value (64-bit).

After the fill command, a window index and an offset must be supplied, in that order. This specifies the memory access window to be written, and where in that window to begin writing data. An optional length parameter, in bytes, can also be supplied. If omitted, the length is equal to the word width implied by the write command. If present, the length parameter specifies how many bytes to write. The length should be an integer multiple of the width; if not, the length is rounded down.

The fill value is obtained in one of two ways: from an additional parameter on the command line after the length parameter, or from the standard input stream (stdin). There can be only one fill value.

Assuming that the target FPGA is currently configured with an FPGA bitstream which has a RAM-like region in the OCP/AXI address space of the Direct Slave channel at address 0x80000, an example session looks like this:

```
[root@localhost dump]# ./dump rd 0 0x80000 0x40
Dump of memory at 0x00000000 00080000 + 64 (0x40) bytes:
      00      04      08      0C
0x00000000_00080000: 00000000 00000000 00000000 00000000 .....
0x00000000_00080010: 00000000 00000000 00000000 00000000 .....
0x00000000_00080020: 00000000 00000000 00000000 00000000 .....
0x00000000_00080030: 00000000 00000000 00000000 00000000 .....
[root@localhost dump]# ./dump wd 0 0x80004 0x8 0xdeadbeef 0xcafeface
0x00000000_00080004: 0xDEADBEEF
0x00000000_00080008: 0xCAFEFACE
[root@localhost dump]# ./dump fw 0 0x80006 0x4 0x1234
Fill value: 0x1234
[root@localhost dump]# ./dump rd 0 0x80000 0x40
Dump of memory at 0x00000000 00080000 + 64 (0x40) bytes:
      00      04      08      0C
0x00000000_00080000: 00000000 1234BEEF CAFE1234 00000000 .....4.4.....
0x00000000_00080010: 00000000 00000000 00000000 00000000 .....
0x00000000_00080020: 00000000 00000000 00000000 00000000 .....
0x00000000_00080030: 00000000 00000000 00000000 00000000 .....
```

Remarks

When entering data for write commands, values are expressed in decimal by default. To express data as hexadecimal, prefix it with '0x' or use the **+hex** option.

The **DUMP** utility uses store instructions for writes whose widths correspond to the word width specified on the command line, if possible. This is not possible if the CPU architecture in use does not have store instructions of the required width or if the offset specified on the command line would result in unaligned stores. In the case of an unaligned offset, writes are performed as a sequence of byte stores, because unaligned stores are illegal on some CPU architectures. FPGA designs that use byte enables to mask writes to byte lanes will work correctly regardless of the size of a store instruction generated by the compiler.

The Direct Slave address space is separate from the address space of each DMA engine. This means that in general, writing data using the **DUMP** utility and attempting to read it back via the **DMADUMP** utility will not return the same data. However, it is possible to create an FPGA design which explicitly makes a shared resource available in both the Direct Slave address space and the address space of a DMA engine. In that case, data written by one channel can be read back via another channel.

3.5 FLASH utility

Command line

```
flash [option ...] info      target-index
flash [option ...] chkblank target-index
flash [option ...] erase     target-index
flash [option ...] program   target-index filename
flash [option ...] verify    target-index filename
```

where

target-index is the index of a target FPGA.
filename is the name of a .BIT file (program or verify commands only).

and the following options are accepted:

-index <index> Specifies the index of the card to open (default 0).
-sn <#> Specifies the serial number of the card to open.
-failsafe Causes the command to target the default region of the Flash.
+failsafe Causes the command to target the failsafe of the Flash; see [Section 3.5.1](#) below.
+force Causes a mismatch between the target FPGA device and the .BIT file device to be ignored.
-force Causes a mismatch between the target FPGA device and the .BIT file device to result in an error (default).
-range <address>,<length> Overrides the program logic that determines how to map a region index to a range of Flash addresses. See [Section 3.5.1](#) below.
-region <n> Causes the command to target region *n* of the Flash; see [Section 3.5.1](#) below.

The **-failsafe**, **-range** and **-region** options are all mutually exclusive to one another; at most, one of these options can be passed on the command line.

Summary

Blank-checks, erases, programs or verifies a target FPGA bitstream region in the user-programmable Flash memory of a device.

Description

The **FLASH** utility has five commands:

- **chkblank <target-index>**
Verifies that a region is blank, i.e. all bytes are 0xFF.
- **erase <target-index>**
Erases a region so that it becomes blank, i.e. all bytes are 0xFF.
- **info <target-index>**
Displays information about the Flash memory that holds a region.
- **program <target-index> <filename>**
Programs the specified bitstream (.BIT) file into a region so that the target FPGA is configured from a particular region at power-on or reset.
- **verify <target-index> <filename>**
Verifies that a region contains the specified bitstream (.BIT) file.

chkblank command

The **chkblank** command verifies that a target FPGA region is blank, i.e. all bytes are 0xFF, but does not modify the Flash memory bank. Following the command, an index of a target FPGA in the device must be specified. The index of the target FPGA is normally zero but may be nonzero in models with multiple target FPGAs.

For example, to blank-check the default region for target FPGA 0:

```
flash chkblank 0
```

erase command

The **erase** command erases a target FPGA region so that it becomes blank, i.e. all bytes are 0xFF. It automatically performs a blank-check after erasing. Following the command, an index of a target FPGA in the device must be specified. The index of the target FPGA is normally zero but may be nonzero in models with multiple target FPGAs.

For example, to erase the default region for target FPGA 0:

```
flash erase 0
```

info command

The **info** command displays information about the Flash memory and then exits, without doing anything else. Following the command, an index of a target FPGA in the device must be specified. The index of the target FPGA is normally zero but may be nonzero in models with multiple target FPGAs. For example:

```
flash info 0
```

program command

The **program** command programs a target FPGA region with the data in the specified bitstream (.BIT) file. Following the command, an index of a target FPGA in the device and the name of a bitstream (.BIT) filename must be specified. The index of the target FPGA is normally zero but may be nonzero in models with multiple target FPGAs.

If the device in the .BIT file does not match the target FPGA, this command fails with an error and does not program the target FPGA region, unless the **+force** option is passed. Verification is automatically performed after programming.

For example, to program the default region for target FPGA 0 with a bitstream file called **my_design.bit**:

```
flash program 0 /path/to/my_design.bit
```

verify command

The **verify** command verifies that a target FPGA region contains the data in the specified bitstream (.BIT) file, but does not modify the Flash memory bank. Following the command, an index of a target FPGA in the device and the name of a bitstream (.BIT) filename must be specified. The index of the target FPGA is normally zero but may be nonzero in models with multiple target FPGAs.

If the device in the .BIT file does not match the target FPGA, this command fails with an error unless the **+force** option is passed. If discrepancies between the target FPGA region and the data in the .BIT file are found, they are displayed (up to a certain number of erroneous bytes), followed by a failure message.

For example, to verify that the default region for target FPGA 0 contains the data in a bitstream file called **my_design.bit**:

```
flash verify 0 /path/to/my_design.bit
```

3.5.1 Region to address range mapping

WARNING

The **+failsafe**, **-region** and **-range** options must be used with care on models that feature a Virtex-6 target FPGA, because they can be used to overwrite the **failsafe region** of the Flash memory. The failsafe region is factory-programmed with a bitstream that protects against sub-micron effects that might otherwise degrade the performance of the target FPGA over time.

[Xilinx answer record 35055](#) elaborates on protecting Virtex-6 GTX transceivers from performance degradation over time.

Alpha Data recommends that the failsafe region should not be erased or overwritten. If overwritten on a model that features a Virtex-6 target FPGA, the customer must ensure that it is written with a valid, known-good bitstream that satisfies the requirements for protecting the target FPGA from sub-micron effects.

Most of Alpha Data's reconfigurable computing cards have Flash memory capable of storing multiple **.bit** files, and are divided into two or more regions. The address map for each Flash memory bank, including information about regions, is presented in the [ADMXRC3 API Hardware Addendum](#).

The default behaviour of the **chkblank**, **erase**, **program** and **verify** commands is to use the **default region** of the Flash memory bank, which varies between models. A region is identified by its zero-based index. For example, for the ADM-XRC-6T1, the default region is 0.

The **+failsafe** option modifies the behaviour of the **flash** utility so that it targets the **failsafe region**. This is a region of Flash, with a different index to that of the default region. For example, for the ADM-XRC-6T1, the failsafe region is 1. The failsafe region normally contains a factory-programmed bitstream that serves one of two purposes:

- In models which feature a dedicated, non-user-programmable PCIe interface chip, such as the ADM-XRC-6T1, the failsafe region is used to configure the target FPGA at power-on if a valid bitstream is not found in the default region. As noted in the warning above, this protects the target FPGA from sub-micron effects that might otherwise degrade the performance of the target FPGA over time.
- In models which feature a single FPGA that serves as both PCIe interface and target FPGA, such as the ADM-PCIE-7V3, the failsafe region can be selected by switches so that the FPGA is configured with the failsafe bitstream at power-on. This enables recovery from programming a "bad" **.bit** file into the default region. Here, a "bad" **.bit** file is defined to be one that does not include a working PCIe interface, thus preventing further Flash programming via PCIe.

The **-region** option supports models that have more than two regions, such as the ADM-PCIE-7V3. It must be followed by an argument that is the region index, e.g. **-region 0**. The **-region** option can be used to target the failsafe region or the default region (or any other region in models with more than two regions) by passing the appropriate region index as the argument.

The final option that modifies the behaviour of **flash** utility is the **-range** option. This option overrides the program logic that maps a region index to a range of Flash memory addresses, and must be followed by an argument of the form **<address>**, **<length>**. This option can be used to achieve the same effect as **+failsafe** and **-region** options, provided that the user knows the correct address range to use. Refer to the [ADMXRC3 API Hardware Addendum](#) for Flash memory bank address maps, by model.

Some examples of using the above three options follow:

- The following commands are all equivalent on the ADM-XRC-6T1, and perform a blank-check on the failsafe region (1), which should fail assuming that the factory-programmed bitstream is still present:

```
flash +failsafe chkblank 0  
flash -region 1 chkblank 0
```

```
flash -range 2900000,1700000 chkblank 0
```

- The following commands are all equivalent on the ADM-PCIE-7V3, and write a bitstream into the default region (1):

```
flash program 0 /path/to/my_design.bit
flash -failsafe program 0 /path/to/my_design.bit
flash -region 1 program 0 /path/to/my_design.bit
flash -range 2000000,2000000 program 0 /path/to/my_design.bit
```
- On the ADM-PCIE-7V3, the following commands write and then verify a small compressed bitstream (must be less than or equal to 10 MiB) in the uppermost 10 MiB of region 3:

```
flash -range 7600000,A000000 program 0 /path/to/my_design.bit
flash -range 7600000,A000000 verify 0 /path/to/my_design.bit
```

3.6 INFO utility

Command line

```
info [option ...]
```

where the following options are accepted:

-flash	Causes Flash bank information not to be shown (default).
+flash	Causes Flash bank information to be shown.
-index <index>	Specifies the index of the card to open (default 0).
-io	Causes I/O module information not to be shown (default).
+io	Causes I/O module information to be shown.
-sensor	Causes sensor information not to be shown (default).
+sensor	Causes sensor information to be shown.
-sn <#>	Specifies the serial number of the card to open.

Summary

Displays information about a reconfigurable computing device.

Description

The **INFO** utility demonstrates the use of most of the informational functions in the **ADMXRC3** API. It uses **ADMXRC3_OpenEx** to open a device in passive mode, meaning that an unprivileged user can successfully run it. The output consists of several sections, the first of which is obtained using **ADMXRC3_GetVersionInfo**:

```
API information
API library version      1.1.1
Driver version           1.1.1
```

The second section shows information obtained using **ADMXRC3_GetCardInfoEx**, and shows the information in the **ADMXRC3_CARD_INFOEX** structure:

```
Card information
Model                ADM-XRC-6TL
Serial number        101 (0x65)
Number of programmable clocks  1
Number of DMA channels  1
Number of target FPGAs  1
Number of local bus windows  4
```

```
Number of sensors          10
Number of I/O module sites 1
Number of local bus windows 4
Number of memory banks     4
Bank presence bitmap       0xF
```

The third section uses the **NumTargetFpga** member of the **ADMXRC3_CARD_INFOEX** structure and **ADMXRC3_GetFpgaInfo** to enumerate the target FPGAs in the device:

```
Target FPGA information
FPGA 0                      xc6v1x240tff1759
```

The fourth section uses the **NumMemoryBank** member of the **ADMXRC3_CARD_INFOEX** structure and **ADMXRC3_GetBankInfo** to enumerate the memory banks (non-Flash) in the device:

```
Memory bank information
Bank 0                      SDRAM, DDR3, 65536 kiWord x 32+0 bits
                             303.0 MHz - 533.3 MHz
                             Connectivity mask 0x1
Bank 1                      SDRAM, DDR3, 65536 kiWord x 32+0 bits
                             303.0 MHz - 533.3 MHz
                             Connectivity mask 0x1
Bank 2                      SDRAM, DDR3, 65536 kiWord x 32+0 bits
                             303.0 MHz - 533.3 MHz
                             Connectivity mask 0x1
Bank 3                      SDRAM, DDR3, 65536 kiWord x 32+0 bits
                             303.0 MHz - 533.3 MHz
                             Connectivity mask 0x1
```

The fourth section uses the **NumWindow** member of the **ADMXRC3_CARD_INFOEX** structure and **ADMXRC3_GetWindowInfo** to enumerate the memory access windows in the device:

```
Local bus window information
Window 0 (Target FPGA 0 pre Bus base 0xF5400000 size 0x400000
                             Local base 0x0 size 0x400000
                             Virtual size 0x400000
Window 1 (Target FPGA 0 non Bus base 0xFAC00000 size 0x400000
                             Local base 0x0 size 0x400000
                             Virtual size 0x400000
Window 2 (ADM-XRC-6TL-speci Bus base 0xFAAFF000 size 0x1000
                             Local base 0x0 size 0x0
                             Virtual size 0x1000
Window 3 (ADB3 bridge regis Bus base 0xFAAFE000 size 0x1000
                             Local base 0x0 size 0x0
                             Virtual size 0x1000
```

The next section appears if the **+flash** option is passed on the command line. It uses the **NumFlashBank** member of the **ADMXRC3_CARD_INFOEX** structure and **ADMXRC3_GetFlashInfo** to enumerate the Flash memory banks in the device:

```
Flash bank information
Bank 0                      Intel 28F256P30, 65536(0x10000) kiB
                             Usable area 0x1200000-0x3FFFFFFF
```

The next section appears if the **+io** option is passed on the command line. It uses the **NumModuleSite** member of the **ADMXRC3_CARD_INFOEX** structure and **ADMXRC3_GetModuleInfo** to enumerate the I/O module sites in the device and show what is fitted, if anything:

```
I/O module information
Module 0                    Not present
```

The final section appears if the **+sensor** option is passed on the command line. It uses the **NumSensor** member of the **ADMXRC3_CARD_INFOEX** structure and **ADMXRC3_GetSensorInfo** to enumerate the sensors in the device:

```
Sensor information
Sensor 0                    1V supply rail
```

Sensor 1	V, double, exponent 0, error 0.0 1.5V supply rail
Sensor 2	V, double, exponent 0, error 0.0 1.8V supply rail
Sensor 3	V, double, exponent 0, error 0.0 2.5V supply rail
Sensor 4	V, double, exponent 0, error 0.1 3.3V supply rail
Sensor 5	V, double, exponent 0, error 0.1 5V supply rail
Sensor 6	V, double, exponent 0, error 0.1 XMC variable power rail
Sensor 7	V, double, exponent 0, error 0.2 XRM I/O voltage
Sensor 8	V, double, exponent 0, error 0.1 LM87 internal temperature
Sensor 9	deg. C, double, exponent 0, error 3.0 Target FPGA temperature
	deg. C, double, exponent 0, error 4.0

3.7 IPROG utility

Command line

```
iprog [option ...] abort      target-index
iprog [option ...] from-now  target-index address [delay-ms]
iprog [option ...] on-stop   target-index address [delay-ms]
iprog [option ...] status    target-index
```

where

<i>target-index</i>	is the index of a target FPGA.
<i>address</i>	specifies where in Flash memory the SelectMap data begins, and can be a region index, a Flash address (hex), or a WBSTAR register value. See below for details.
<i>delay-ms</i>	is the reconfiguration countdown time, in milliseconds (optional, default 30000).

and the following options are accepted:

-index <index>	Specifies the index of the card to open (default 0).
-sn <#>	Specifies the serial number of the card to open.
-verbose	Suppresses most informational messages (default).
+verbose	Displays informational messages.

Summary

Initiates or aborts software-initiated reconfiguration of the target FPGA on models that support it.

Description

The **IPROG** utility has four commands:

- **abort <target-index>**
Aborts software-initiated reconfiguration of the target FPGA.

- **from-now** <target-index> <address> [delay-ms]
Schedules software-initiated reconfiguration to occur *delay-ms* milliseconds from when the command is issued.
- **on-stop** <target-index> <address> [delay-ms]
Schedules software-initiated reconfiguration to occur *delay-ms* milliseconds from when the device is stopped (i.e. by unloading ADB3 Driver).
- **status** <target-index>
Displays whether or not software-initiated reconfiguration is currently scheduled, and the remaining countdown time if scheduled.

abort command

The **abort** command aborts software-initiated reconfiguration of the target FPGA. The first argument is the index of the target FPGA for which reconfiguration is to be aborted.



For example, to abort software-initiated reconfiguration of target FPGA 0:

```
iprog abort 0
```

from-now & on-stop commands

The **from-now** command schedules software-initiated reconfiguration to occur at a particular time from when the command is issued, whereas the **on-stop** command schedules software-initiated reconfiguration to occur at a particular time from when the device is stopped (i.e. the ADB3 Driver is unloaded). The **on-stop** command is generally preferable to **from-now** because the former more or less eliminates the risk that the target FPGA is reconfigured while the ADB3 Driver is communicating with it.

For both commands, the first argument is the index of the target FPGA to be reconfigured. This must be followed by a value that indicates from where in Flash memory the SelectMap data is obtained, which must be in one of the following forms:

- **address:<a>**
where <a> is a hexadecimal number representing the byte address in Flash memory at which the SelectMap data begins. Details of Flash memory maps, by model, are found in [ADMXRC3 API Hardware Addendum](#) .
- **region:<i>**
where <i> is the decimal zero-based index of a region of Flash memory, as described in [ADMXRC3 API Hardware Addendum](#) .
- **wbstar:<value>**
where <value> is a hexadecimal number which is the value for the WBSTAR register in the ICAP interface of a 7 Series FPGA. Refer to Xilinx UG470, "IPROG Reconfiguration" for further details.

The last argument, which is optional, is the countdown delay in milliseconds (default 30000). For the **from-now** command, it is the delay from issuing the command to when the FPGA is reconfigured. For the **on-stop** command, it is the delay from stopping the device (i.e. unloading the ADB3 Driver) to when the FPGA is reconfigured. The default of 30 seconds is intended to provide sufficient time to stop the device even in a system which is heavily loaded. For the **on-stop** command, a delay of 2000 milliseconds is expected to be safe, and a value of less than 500 milliseconds is not recommended except in a lightly-loaded system.

For example, to schedule software-initiated reconfiguration after 15 seconds, from the beginning of region 1 of the Flash memory on an ADM-PCIE-7V3, the following commands are all equivalent:

```
iprog from-now 0 address:2000000 15000
iprog from-now 0 region:1 15000
iprog from-now 0 wbstar:60000000 15000
```


To schedule software-initiated reconfiguration after 2 seconds from device stop, from the middle of region 1 of the Flash memory on an ADM-PCIE-7V3, the following two commands are equivalent:

```
iprog on-stop 0 address:3000000 2000
iprog on-stop 0 wbstar:60800000 2000
```

status command

The **status** command displays whether or not software-initiated reconfiguration is currently scheduled and how much time remains for the countdown. The first argument is the index of the target FPGA for which status is to be requested.

For example, to request the status of software-initiated reconfiguration of target FPGA 0:

```
iprog status 0
```

3.8 LOADER utility

Command line

```
loader [option ...] <target FPGA index> <bitstream filename>
```

where the following options are accepted:

-index <index>	Specifies the index of the card to open (default 0).
-sn <#>	Specifies the serial number of the card to open.
-binary	Treat <bitstream filename> as a .bit file, and attempt to parse it accordingly.
+binary	Treat <bitstream filename> as a binary file containing only SelectMap data.
-checklink	Do not verify that communications with the target FPGA have been established before exiting.
+checklink	Verify that communications with the target FPGA have been established before exiting (default).



Summary

Configures a target FPGA with a .bit file, and then exits.

Description

The **LOADER** utility configures the target FPGA, identified by <target FPGA index>, within a reconfigurable computing device with the bitstream file identified by <bitstream filename>, and then exits.

By default, **LOADER** expects <bitstream filename> to name a .bit file, i.e. a file generated by the **bitgen** tool in the Xilinx ISE toolset, and attempts to parse the file accordingly. However, the **+binary** option causes **LOADER** to treat <bitstream filename> as a file containing raw SelectMap data. Such a file can be obtained in a number of ways, including a user-created program or by using the **BITSTRIP** utility.

Because the **LOADER** utility uses [ADMXRC3_ConfigureFromFile](#)  or [ADMXRC3_ConfigureFromBuffer](#) , it normally checks that communications with the target FPGA have been established before exiting. Passing the **-checklink** option causes this check to be omitted, and is needed for an FPGA design that has no host interface (i.e. no OCP communication) with the host, such as a stand-alone Ethernet design.

3.9 MONITOR utility

Command line

```
monitor [option ...]
```

where the following options are accepted:

-index <index>	Specifies the index of the card to open (default 0).
-period <delay>	Specifies the update period, in seconds.
-repeat <n>	Specifies the number of updates to perform (default 0); a value of zero means "repeat for ever".
-sn <#>	Specifies the serial number of the card to open.

Summary

Displays readings from all sensors.

Description

The **MONITOR** utility repeatedly displays sensor readings in the command shell at the interval specified by the **-period** option. The number of updates to perform before terminating can be specified on the command line using the **-repeat** option, but by default, the program runs until interrupted with CTRL-C.

It makes use of the [ADMXRC3_GetSensorInfo](#) and [ADMXRC3_ReadSensor](#) functions from the ADMXRC3 API, and because it opens a device in passive mode using [ADMXRC3_OpenEx](#), it can run alongside other reconfigurable computing applications without disturbing them.

The output looks like this:

```
Model: 257 (0x101) => ADM-XRC-6TL
Serial number: 101 (0x65)
Number of sensors: 10
Sensor 0 1V supply rail: 0.987000 V
Sensor 1 1.5V supply rail: 1.509186 V
Sensor 2 1.8V supply rail: 1.803192 V
Sensor 3 2.5V supply rail: 2.508896 V
Sensor 4 3.3V supply rail: 3.268082 V
Sensor 5 5V supply rail: 5.017990 V
Sensor 6 XMC variable power rail: 12.000000 V
Sensor 7 XRM I/O voltage: 2.495712 V
Sensor 8 LM87 internal temperature: 49.000000 deg C
Sensor 9 Target FPGA temperature: 57.000000 deg C
```

3.10 SYSMON utility

Command line

```
sysmon
```

Summary

Utility presenting device information and hardware sensors in a graphical user interface.

Description

The **SYSMON** utility combines the information shown by the **INFO** and **MONITOR** utilities with a graphical user

interface. Its main function is graphical display of hardware sensor data, and it can be minimized to the notification area of the desktop (the "System Tray" in Windows) in order to run unobtrusively.

It makes use of the `ADMXRC3_GetSensorInfo` and `ADMXRC3_ReadSensor` functions from the ADMXRC3 API, and because it initially opens a device in passive mode using `ADMXRC3_OpenEx`, it can run alongside other reconfigurable computing applications without disturbing them.

The user interface of the Linux version of SYSMON is as follows, upon starting the utility:




Figure 2 : SYSMON user interface

Referring to Figure 2, the user interface elements are as follows:

- 1 A combo box that specifies which reconfigurable computing device to use.
- 2 A combo box that selects the time interval between sensor readings.
- 3 A button that reveals the **Action** menu when clicked. The **Action** menu allows sensor data logging as described in Section 3.10.6 below. The Windows version of SYSMON does not have this button, but instead hosts equivalent functionality via the system menu.
- 4 A tab control whose tabs are as follows:
 - The **device information tab** shows information about the currently selected device.
 - The **sensor information tab** shows information about the available sensors in the currently selected device.
 - The **sensor readout tab** displays sensor data graphically in up to four 'scopes'.
 - The **device status tab** displays any error conditions in the currently selected device, and permits them to be cleared if the user that launched SYSMON has the necessary privileges.
 - The **clock generator tab** displays clock generator frequencies for the currently selected device, and permits them to be changed if the user that launched SYSMON has the necessary privileges.

When minimized (item 5), **sysmon** appears in the notification area of the desktop:



Figure 3 : SYSMON notification area icon

The icon shown in the notification area has a context menu activated by a right-click, and this can be used to restore the application to the desktop, as well as offering the same logging functions as the **Action** menu. Refer to [Section 3.10.6](#) for a description of data logging.

To actually close the application as opposed to minimizing it, click the close button of the window.

3.10.1 SYSMON device information tab

The set of information shown in the device information tab is approximately the same as that shown by the command-line [INFO](#) utility, but with a collapsible tree structure.

3.10.2 SYSMON sensor information tab

The sensor information tab is a tabular view of the available sensors, including the current reading for each sensor:

ADMXRC3 Diagnostics			
Device		Update period	Action...
Index 0 ADM-XRC-7K1 SN #105		1 s	
Device Information Sensor Information Sensor Readout Device Status Clock Generators			
#	Description	Value	Unit
0	5V/12V XMC VPWR rail	12.1	V
1	12V XMC power rail	12.1	V
2	5V XMC power rail	4.98	V
3	3.3V XMC power rail	3.25	V
4	2.5V power rail	2.48	V
5	2.0V VCC aux. I/O rail	2	V
6	1.8V power rail	1.79	V
7	1.8V MGT AVCC aux.	1.83	V
8	1.5V DDR3 SDRAM power rail	1.51	V
9	XRM variable V/I/O rail	1.82	V
10	1.0V power rail	1.01	V
11	1.2V Target FPGA AVCC	1.2	V

Figure 4 : SYSMON sensor information tab

3.10.3 SYSMON sensor readout tab

The sensor readout tab displays sensor readings in graphical form:




Figure 5 : SYSMON sensor readout tab

Initially, the 'scope' is empty and displays no sensors. The above figure shows two scopes, one showing temperatures and the other showing voltages. The user interface elements of the 'scope' toolbar are as follows:

- 5 The temperature button sets the 'scope' to display all temperature sensors in the device, and starts updates.
- 6 The voltage button sets the 'scope' to display all voltage sensors in the device, and starts updates.
- 7 The current button sets the 'scope' to display all current sensors in the device, and starts updates.
- 8 Mouse over the key to see which sensor corresponds to which coloured trace.
- 9 The pause / resume button can be used to pause and resume update of the 'scope'.
- 10 A button that adds another 'scope' when clicked, to a maximum of 4, so that various types of sensor can be viewed at the same time.
- 11 A button that destroys a 'scope' when clicked. If there is only one 'scope', the button is disabled.

3.10.4 SYSMON device status tab

The device status tab shows any error conditions that are present for a device, and allows the user to clear error conditions, provided that he or she has sufficient privileges:




Figure 6 : SYSMON device status tab

The **Clear Errors** button, labeled 12 in Figure 6, allows device errors to be cleared, but in order for this button to be functional, **SYSMON** must be launched by a user with sufficient privileges to reopen the device in active mode. This works follows:

- In Linux, **SYSMON** must be launched by a user that has privileges to reopen the device in active mode. The **Clear Errors** button will then be functional.
In most cases, this means that the user must be **root**, but if the system administrator has customized the **udev** rules file for the **ADB3 Driver**, it is possible for non-root users to have privileges to reopen the device in active mode.
- In versions of Windows without User Account Control (UAC), i.e. Windows XP and earlier, **SYSMON** must be launched by a user in the Administrators group. The **Clear Errors** button will then be functional.
- In versions of Windows with User Account Control (UAC), i.e. Windows Vista and earlier, **SYSMON** must be launched by a user in the Administrators group. If the **Clear Errors** button is clicked and **SYSMON** is not running elevated, **SYSMON** re-launches itself elevated (this will incur a UAC prompt). The **Clear Errors** button will then be functional.

Alternatively, launch **SYSMON** elevated by right-clicking on its shortcut or executable file and selecting "Run as administrator". The **Clear Errors** button will then be functional.

3.10.5 SYSMON clock generator tab

The clock generator tab shows current frequencies of clock generators, and allows the user to change their frequencies, provided that he or she has sufficient privileges:




Figure 7 : SYSMON clock generator tab

In Linux, provided that **SYSMON** has been launched by a user with privileges to reopen the device in active mode, frequencies can be changed by clicking on them and entering a new frequency. In most cases, this means that the user must be **root**, but if the system administrator has customized the **udev** rules file for the **ADB3 Driver**, it is possible for non-root users to have privileges to reopen the device in active mode.

In Windows, provided that **SYSMON** is executing elevated so that it can reopen the device in active mode, frequencies can be double-clicked and a new frequency entered in order to change them. This works as follows:

- In versions of Windows without User Account Control (UAC), i.e. Windows XP and earlier, **SYSMON** must be launched by a user in the Administrators group, which means that it runs elevated. This is sufficient to allow frequencies to be changed.
- In versions of Windows with User Account Control (UAC), i.e. Windows Vista and earlier, **SYSMON** must be launched by a user in the Administrators group, which enables the **Allow Changes** button (labeled 13 in Figure 7). Clicking **Allow Changes** causes **SYSMON** to re-launch itself elevated. Once **SYSMON** is running elevated, frequencies can be changed.

Alternatively, launch **SYSMON** elevated by right-clicking on its shortcut or executable file and selecting "Run as administrator". This will permit frequencies to be changed.

3.10.6 SYSMON sensor data logging

In Linux, SYSMON can log sensor data over an arbitrary time period via the **Action** menu:




Figure 8 : SYSMON Action menu in Linux

In Windows, the **Action** button is not present, and the **Action** menu items are located in the system menu:




Figure 9 : SYSMON Action menu in Windows

Data logging works as follows:

- The **Start new log file** option prompts for a filename into which sensor data is to be logged. If a file of that name already exists, it will be overwritten.
- The **Append to log file** option prompts for a filename into which sensor data is to be logged, but unlike **Start new log file**, if a file of that name already exists, new data will be appended to it.
- The **Stop logging** option is only enabled after logging has successfully been started using **Start new log file** or **Append to log file**, and causes SYSMON to cease logging data.

The files created are in comma-separated value (CSV) format (some rows and columns deleted for brevity):

```
START,11:59:07 23 Aug 2011
COMMENT,MODEL,SERIAL#
DEVICE,ADM-XRC-6TL,102
COMMENT,SENSOR#,Description,Unit
SENSOR,0,1V supply rail,V
SENSOR,1,1.5V supply rail,V
SENSOR,2,1.8V supply rail,V
SENSOR,3,2.5V supply rail,V
...
SENSOR,12,Bridge VCCAUX,V
COMMENT,TIMESTAMP,1V supply rail,1.5V supply rail,1.8V supply rail,2.5V supply rail,...
COMMENT,ms,V,V,V,V,...
DATA,583,0.987000,1.509186,1.812988,2.508896,...
DATA,1584,0.987000,1.509186,1.812988,2.508896,...
DATA,2645,0.987000,1.509186,1.812988,2.508896,...
DATA,3646,0.987000,1.509186,1.812988,2.508896,...
```



```
...  
DATA,13661,0.987000,1.509186,1.812988,2.508896,...  
DATA,14663,0.987000,1.509186,1.812988,2.508896,...  
STOP,11:59:22 23 Aug 2011
```

The string in column 1 of each row indicates what information a row contains:

- **START** signifies the start of a logging session, in case the file contains multiple sessions that were obtained using the **Append to log file** option.
- **STOP** signifies the end of a logging session, in case the file contains multiple sessions that were obtained using the **Append to log file** option.
- **COMMENT** signifies a comment, for the benefit of human readers, and can be filtered out by a program that reads the file.
- **DEVICE** identifies the model and serial number, in the second and third cells respectively, of the physical card from which the data was collected.
- **SENSOR** signifies information about a sensor. The second cell is the sensor index, the third cell is the sensor's description and the fourth cell is the unit for that sensor.
- **DATA** signifies a set of sensor readings at a given instant. The second cell is a timestamp, in milliseconds, relative to the time and date in the **START** row. The third and subsequent cells are individual sensor values, where the third cell corresponds to the **SENSOR** row whose sensor index is 0, the fourth cell corresponds to the **SENSOR** row whose sensor index is 1 etc.

3.11 VPD utility

Command line

```
vpd [option ...] fb address n [data]  
vpd [option ...] fw address n [data]  
vpd [option ...] fd address n [data]  
vpd [option ...] fq address n [data]  
vpd [option ...] fs address n [string]  
vpd [option ...] rb address [n]  
vpd [option ...] rw address [n]  
vpd [option ...] rd address [n]  
vpd [option ...] rq address [n]  
vpd [option ...] wb address [n] [data ...]  
vpd [option ...] ww address [n] [data ...]  
vpd [option ...] wd address [n] [data ...]  
vpd [option ...] wq address [n] [data ...]  
vpd [option ...] ws address [n] [string ...]
```

where

<i>address</i>	is the address in VPD memory at which to begin reading or writing.
<i>n</i>	is the number of bytes to read or write.
<i>data</i>	is a numeric data item, valid for fill and write commands.
<i>string</i>	is a string data item, valid for fill and write commands.

and the following options are accepted:

-index <index>	Specifies the index of the card to open (default 0).
-sn <#>	Specifies the serial number of the card to open.
-hex	Causes numeric data values to be interpreted as decimal unless prefixed by '0x' (default).
+hex	Causes numeric data values to be interpreted as hexadecimal always.

Summary

Displays data read from VPD memory, or writes data to VPD memory.

Description

The **VPD** utility operates in one of three modes:

- Filling a region of VPD memory with a value or string; for this mode, use the **fb**, **fw**, **fd**, **fq** or **fs** commands.
- Reading data from VPD memory and displaying it; for this mode, use the **rb**, **rw**, **rd** or **rq** commands.
- Writing numeric or string data to a region of VPD memory; for this mode, use the **wb**, **ww**, **wd**, **wq** or **ws** commands.

Fill commands

When filling a region of VPD memory with data, the fill command specifies whether the data is numeric or string data. In the case of numeric data, the command also implies the word width of the data. The available fill commands are:

- **fb**
Fill value is a byte (8-bit).
- **fw**
Fill value is a word (16-bit).
- **fd**
Fill value is a doubleword (32-bit).
- **fq**
Fill value is a quadword (64-bit).
- **fs**
Fill value is an ASCII string (8-bit characters).

The next 3 arguments after the fill command must be:

- (a) *address* - the byte address within VPD memory at which to begin filling.
- (b) *n* - byte count; the number of bytes of VPD memory to fill.
- (c) *data* or *string* - the numeric or string value to place in the specified region of VPD memory.

If the command is **fs** and the string value is shorter than the byte count *n*, the string is repeated until the byte count is satisfied. If the string is longer than the byte count *n*, only the first *n* characters are used. If a string contains spaces, it must be quoted on the command line so that it is not interpreted by the shell as two or more separate arguments.

For the numeric fill commands **fb**, **fw**, **fd** and **fq**, the numeric value is repeated until the byte count is satisfied.

Read commands

The read command implies the word width used for displaying the data:

- **rb**
Byte (8-bit) reads; data is displayed as bytes.
- **rw**
Word (16-bit) reads; data is displayed as words.
- **rd**
Doubleword (32-bit) reads; data is displayed as doublewords.
- **rq**
Quadword (64-bit) reads; data is displayed as quadwords.

After the read command, an address must be supplied, which specifies where in VPD memory to begin reading. An optional length parameter, in bytes, can also be supplied. If omitted, the length is equal to the word width implied by the read command. If present, the length parameter specifies how many bytes to read and display. The length should be an integer multiple of the width; if not, the length is rounded down.

Write commands

The write command specifies whether the data is numeric or string data. In the case of numeric data, the command also implies the word width of the data. The available write commands are:

- **wb**
Data is written as bytes (8-bit).
- **ww**
Data is written as words (16-bit).
- **wd**
Data is written as doublewords (32-bit).
- **wq**
Data is written as quadwords (64-bit).
- **ws**
Data is supplied as one or more ASCII strings (8-bit characters).

After the write command, an address must be supplied, which specifies where in VPD memory to begin writing data. An optional length parameter, in bytes, can also be supplied. If omitted, the length is equal to the word width implied by the write command. If present, the length parameter specifies how many bytes to write. The length should be an integer multiple of the width; if not, the length is rounded down.

The program obtains the values to be written in two ways: from any additional parameters on the command line after the length parameter, and then from the standard input stream (stdin). This works as follows:

- 1 Any remaining command line arguments, if present after the length parameter, are interpreted as data values to be written. Numeric values are assumed to be of the word width implied by the command parameter. As each value is written to VPD memory, the address is incremented. If there are enough values passed on the command line to satisfy the byte count, the program terminates.
- 2 If there are insufficient data values passed on the command line, the program waits for values to be entered on the standard input stream. Numeric values entered this way are also assumed to be of the word width implied by the command. As each value is written to VPD memory, the address is incremented. When the entire byte count that was specified in the length parameter has been satisfied or end-of-file is encountered, the program terminates.

Example session

The following session was captured under Linux using an ADM-XRC-6TL. The base address 0x100000 is used because that is the VPD-space address of the user-definable area of VPD memory in the ADM-XRC-6TL.

```
$ ./vpd rb 0x100000 0x60
Dump of VPD at 0x100000 + 96(0x60) bytes:
 00 01 02 03 04 05 06 07 08 09 0a 0b 0c 0d 0e 0f
0x00100000: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff .....
0x00100010: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff .....
0x00100020: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff .....
0x00100030: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff .....
0x00100040: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff .....
0x00100050: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff .....
$ ./vpd fs 0x100008 20 'hello world!'
$ ./vpd wd 0x100020 12
0x00100020: 0xdeadbeef
0x00100024: 0xcafeface
0x00100028: 0x12345678
$ ./vpd fw 0x100031 10 0xa55a
$ ./vpd rb 0x100000 0x60
Dump of VPD at 0x100000 + 96(0x60) bytes:
 00 01 02 03 04 05 06 07 08 09 0a 0b 0c 0d 0e 0f
0x00100000: ff ff ff ff ff ff ff ff 68 65 6c 6c 20 77 6f .....hello wo
0x00100010: 72 6c 64 21 68 65 6c 6c 6f 20 77 6f ff ff ff ff rld!hello wo...
0x00100020: ef be ad de ce fa fe ca 78 56 34 12 ff ff ff ff .....xV4.....
0x00100030: ff 5a a5 5a a5 5a a5 5a a5 5a ff ff ff ff ff .....2.2.2.2.....
0x00100040: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff .....
0x00100050: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff .....
```

NOTE: the above session assumes that VPD write protection has been disabled as described in the release notes for the ADB3 Driver for Linux or Windows (as appropriate).

Remarks

When entering data for fill or write commands, values are expressed in decimal by default. To express data as hexadecimal, prefix it with '0x' or use the **+hex** option.

In the current version of the **VPD** utility, data is always read from and written to VPD memory in little-endian byte order.

Appendix A: AVR2UTIL clock generator indices

A.1 ADM-XRC-KU1

In the ADM-XRC-KU1, the frequencies of clock generators with indices 1 and 3 may be overridden using the **setclkvnv** command, whereas the clock generators with indices 0 and 2 may not (because their frequencies must be fixed in order for the board to function correctly).

clockgen-index	Net(s) [1]	Purpose	Factory default (MHz)	ADMXRC3 API index [2]	Note
0	REFCLK250M_N0 REFCLK250M_N1	MPTL reference clock	250	N/A	[3]
1	PROGCLK_N0 PROGCLK_N1 PROGCLK_N2	Reference clock for user-definable MGTs	156.25	1	
2	REFCLK300M_N0 REFCLK300M_N1 REFCLK300M_N2 REFCLK300M_N3	Reference clock for DDR4 SDRAM and other logic	300	N/A	[3]
3	FABRIC_CLK_N	General purpose clock	300	2	

Table 2 : AVR2UTIL clock generator indices (ADM-XRC-KU1)

Note:

- [1] For differential clocks, only the negative side of a differential pair is listed.
- [2] This is the clock generator index used in calls such as **ADMXRC3_SetClockFrequency**.
- [3] Not user-programmable. Attempting to set an override frequency using **AVR2UTIL** will fail with exit code 103. Not exposed by ADMXRC3 API.

A.2 ADM-PCIE-8V3

In the ADM-PCIE-8V3, the frequencies of clock generators with indices 0, 1 and 2 may be overridden using the **setclkvnv** command, whereas the clock generator with index 3 may not (because its frequency must be fixed in order for the board to function correctly).

clockgen-index	Net(s) [1]	Purpose	Factory default (MHz)	ADMXRC3 API index [2]	Note
0	GTY_CLK_0B_N GTY_CLK_0C_N	QSFP+ 0 reference clock QSFP+ 1 reference clock	161.1328125	0	
1	GTY_CLK_1B_N GTY_CLK_1C_N	FireFly 0 reference clock FireFly 1 reference clock	161.1328125	1	
2	MEM_CLK_0_N MEM_CLK_1_N	Reference clock for DDR4 SDRAM	300	2	
3	FABRIC_CLK_N	General purpose clock	300	N/A	[3]

Table 3 : AVR2UTIL clock generator indices (ADM-PCIE-8V3)

Note:

- [1] For differential clocks, only the negative side of a differential pair is listed.
- [2] This is the clock generator index used in calls such as **ADMXRC3_SetClockFrequency**.

- [3] Not user-programmable. Attempting to set an override frequency using **AVR2UTIL** will fail with exit code 103. Not exposed by ADMXRC3 API.

A.3 ADM-PCIE-8K5

In the ADM-PCIE-8K5, the frequencies of all four clock generators, with indices 0 to 3, may be overridden using the **setclknv** command.

clockgen-index	Net(s) [1]	Purpose	Factory default (MHz)	ADMXRC3 API index [2]	Note
0	GTY_CLK_0_N	SFP+ 0 reference clock	156.25	0	
1	GTY_CLK_1_N	SFP+ 1 reference clock	156.25	1	
2	MEM_CLK_0_N MEM_CLK_1_N	Reference clock for DDR4 SDRAM	300	2	
3	GTH_CLK_2_N	FireFly 1 reference clock	156.25	3	

Table 4 : AVR2UTIL clock generator indices (ADM-PCIE-8K5)

Note:

- [1] For differential clocks, only the negative side of a differential pair is listed.
- [2] This is the clock generator index used in calls such as **ADMXRC3_SetClockFrequency**.

Revision History

Date	Revision	Nature of change
12 Aug 2015	1.0	Initial version.
16 May 2016	1.1	Documented new utility: avr2util. Documented support for new models: ADM-XRC-KU1, ADM-PCIE-8V3, ADM-PCIE-8K5.